HOW TO USE THE SCALE

Press \circlearrowleft button to switch on the scale and wait until "0.0" is shown on the display screen. Place the object(s) on the center of the platform. When the display is stable check the readout. Press M button to switch between the weighing units. Press \circlearrowleft again to turn off the scale after use.

HOW TO USE TARE FUNCTION

Turn on the scale. Place the empty container of weighing object(s) on the center of the platform, press T button and the screen shows "0.0". Take the container off and place the item(s) in the container then place the container again on the center of the platform. The readout is the net weight of the item(s) in the container.

HOW TO CALIBRATE THE SCALE

Turn on the scale. Press and hold the **M** button until CAL is shown on the screen. Empty the platform. Press **M** button once and the CAL will blink and then chang to 600.0g. Place a 600 gram calibration weight on the platform. The screen will show PASS then go back to weighing mode. The calibration is completed. If it is still not accurate enough, please calibrate it again.